


# MAGNETON

## ALTERNATOR 9515 530

### IMPORTANT DIMENSIONS TO FIT ON ENGINE



### TECHNICAL DATA

Nominal voltage 14V  
Rated current at 1 800min<sup>-1</sup> 17A  
Rated current at 6 000min<sup>-1</sup> 70A

Maximum speed 13 000min<sup>-1</sup>  
Zero speed 1 300min<sup>-1</sup>  
Weight 4,4kg

### APPLICATIONS

Basic variant without fan and pulley.

1. John Deere

### CROSS REFERENCES

|                     |                                                                               |
|---------------------|-------------------------------------------------------------------------------|
| Bosch               | 0 120 488 217; 0 120 488 218<br>0 120 489 156; 0 120 489 317<br>0 986 037 450 |
| Delco Remy<br>Lucas | DRA3445; DRA7450<br>LRA01703; LRB00293                                        |
| HC Parts<br>Hella   | CA 1027 IR<br>8EL 432 699-001                                                 |
| John Deere          | AL 67175; AL 67176; AL 57438<br>AZ 31316; TY 6669                             |

11 / 2012

# Náhradní díly alternátoru 9515 530

## Spare parts of alternator 9515 530

Page 3 / 3

|                                                               |       |                  |
|---------------------------------------------------------------|-------|------------------|
| 1.0 Víko přední sestavené<br>Front cover assy                 | ..... | Cat. No. 0135451 |
| 2.0 Rotor sestavený<br>Rotor assy                             | ..... | Cat. No. 0138211 |
| 3.0 Víko zadní sestavené<br>Rear cover assy                   | ..... | Cat. No. 0141201 |
| 4.0 Usměrňovací blok<br>Rectifier                             | ..... | Cat. No. 0140841 |
| 5.0 Držák uhlíků s regulátorem<br>Brush holder with regulator | ..... | Cat. No. 0143411 |
| 6.0 Stator sestavený<br>Stator assy                           | ..... | Cat. No. 0135001 |
| 7.0 Řemenice<br>Pulley                                        | ..... | Cat. No. -       |
| 8.0 Ventilátor<br>Fan                                         | ..... | Cat. No. -       |

### Poznámka Note

1. *Víko přední sestavené je dodáváno včetně předního ložiska.*  
*Front cover assembly is supplied with front bearing.*
2. *Rotor sestavený je dodáván včetně zadního ložiska.*  
*Rotor assembly is supplied with rear bearing.*
3. *Víko zadní sestavené je dodáváno včetně usměrňovače.*  
*Rear cover assembly is supplied with the rectifier.*

