


SERVICE PARTS LIST

GROUP:	36
FORM:	8EM-8EN, 10/95
FILE:	Alternator Parts List Section
DATE:	October, 1995

MODEL	VOLTS	AMPS
Various See Chart		




MODEL NO.	SALES NO.	1 HSNG FRONT	2 ROTOR ASSEM	3 STATOR ASSEM	4 HSNG REAR	5 FAN	6 PULLEY	7 BRNG FRONT	8 BRNG REAR	9 SLIP RING	R.BRNG RET.	11 FIELD DIODE	RECT. BRIDGE
8EM3001GA	110-371	114-227	112-69	113-58	114-222	107-82		111-21	111-21	112-22	111-64	101-208	101-207
8EM3002GA	110-376	114-227	112-70	113-58	114-222	107-68		111-21	111-21	112-22	111-64	101-208	101-207
8EM3002GB	110-376	114-227	112-70	113-58	114-222	107-68		111-21	111-21	112-22	111-64	101-208	101-207
8EM3002GC	110-376	114-227	112-70	113-58	114-222	107-68		111-21	111-21	112-22	111-64	101-208	101-207
8EM3003GA	110-384	114-223	112-70	113-58	114-222	107-68		111-21	111-21	112-22	111-64	101-206	101-207
8EM3004GA	110-394	114-227	112-70	113-58	114-222	107-68		111-21	111-21	112-22	111-64	101-208	101-207
8EN2001FA	110-341	114-223	112-65	113-54	114-222	107-68		111-21	111-21	112-22	111-64	101-206	101-207
BEN2002KA	110-359	114-223	112-64	113-53	114-222	107-68		111-21	111-21	112-22	111-64	101-206	101-207
8EN2003KA	110-360	114-225	112-64	113-53	114-222	107-68		111-21	111-21	112-22	111-64	101-206	101-207
8EN2004KA	110-361	114-223	112-64	113-53	114-222	107-68		111-21	111-21	112-22	111-64	101-206	101-207
8EN2005KA	110-366	114-235	112-64	113-53	114-222	107-68		111-21	111-21	112-22	111-64	101-206	101-207

Important: The information contained in this bulletin is intended for use by trained, professional technicians who have the proper tools, equipment, and training to perform the required maintenance described above. This information is NOT intended for 'do-it-yourselfers', and you should not assume that this information applies to your equipment. If you have any questions regarding this information please visit our website at www.prestolite.com, or contact our technical service department at:



SERVICE PARTS LIST

GROUP: 36



MODEL NO.	SALES NO.	13 D+ STRAP	14 BRUSH ASSEM	15 FAN SPACER	16 WDRFF KEY	17 FELT GASKET	18 COVER ASSEM	19 CAPA- CITOR	20 AC TAP LUG	21 TERM MALE	VOLT. REG.	23 BLANK HSNG	24 CABLE ASSEM
BEM3001GA	110-371	120-334	103-55	120-346		103-56	114-214	120-335			105-269		
BEM3002GA	110-376	120-334	103-55	120-152	120-7	103-56	114-214	120-335			105-270		
8EM3002GB	110-376	120-334	103-55	120-152	120-7	103-56	114-214	120-335			105-270		
8EM3002GC	110-376	120-334	103-55	120-152	120-7	103-56	114-214	120-335			105-270		
ADE008M38	110-384	120-334	103-55	120-152	120-7	103-56	114-214	120-335			105-269		
8EM3004GA	110-394	120-334	103-55	120-152	120-7	103-56	114-214	120-335			105-270		
8EN2001FA	110-341		103-55	120-152	120-7	103-56	114-214	120-335		120-340		114-230	
8EN2002KA	110-359		103-55	120-152	120-7	103-56	114-214	120-335		120-340		114-230	
BEN2003KA	110-360		103-55	120-152	120-7	103-56	114-214	120-335		120-340		114-230	
8EN2004KA	110-361		103-55	120-152	120-7	103-56	114-214	120-335		120-340		114-230	
BEN2005KA	110-366		103-55	120-152	120-7	103-56	114-214	120-335		120-340		114-230	

Important: The information contained in this bulletin is intended for use by trained, professional technicians who have the proper tools, equipment, and training to perform the required maintenance described above. This information is NOT intended for 'do-it-yourselfers', and you should not assume that this information applies to your equipment. If you have any questions regarding this information please visit our website at www.prestolite.com, or contact our technical service department at:



SERVICE PARTS LIST

GROUP: 36

FORM: 8EM-8EN, 10/95

KEY NO.	SALES NO.	DESCRIPTION	8EM3001GA	8EM3002GA	8EM3002GB	8EM3002GC	8EM3003GA	8EM3004GA	8EN2001FA	8EN2002KA	8EN2003KA	8EN2004KA	8EN2005KA								
		BOLTS																			
25	120-336	THROUGH, 10-32 x 2.30*	4	4	4	4	4	4	4	4	4	4	4	-	-		-				
		NUTS													+		+	+	\vdash	\dashv	-
31	120-342	HEX, 1/4-20 x 7/16" CONE LOCK					2		2	2	2,	2	2								Г
31	120-268	HEX, M6 x 1.0	2	2	2	2		2													Г
32	120-148	HEX LOCKNUT, 10-24 x 3/8"	2	2	2	2	6	2	5	5	5	5	5								
32	120-296	HEX, M5 x 0.8	4	5	5	5		5													
35	120-136	PULLEY MOUNTING, 5/8-18	1	1	1	1	1	1	1	1	1	1	1								Γ
37	120-348	HEX SPACER, 10-24 x .73 x.37																			
		SCREWS												+			+	+	\vdash	\dashv	-
26	120-347	W/CONICAL WASHER, 10-32 x 1/2"	3	3	3	3	3	3	3	3	3	3	3								_
27	120-339	MACHINE, 10-24 x 7/8"	2	2	2	2	2	2	2	2	2	2	2								_
28	120-234	TAPPING, 10-24 x 3/8"					1		1	1	1	1	1								
28	120-273	TAPPING, M5 x 10mm	1	1	1	1		1													
29	120-252	TAPPING, 10-32 x 5/8"	8	8	8	8	8	8	8	8	8	8	8								
30	120-121	TAPPING, 8-32 x 5/16"	3	3	3	3	3	3	3	3	3	3	3								
41	120-343	MACHINE, 10-24 x 3/4"					1														
41	120-344	MACHINE, M5 x 3/4"	1	2	2	2		2												-	_
25 1 1 31 1 32 1 32 1 35 1 37 1 1 26 1 1 28 1 1 28 1 1 1 1 1 1 1 1 1 1 1 1 1		WASHERS				-							\vdash	+	+	+		+-		\dashv	-
33	120-109	FLAT METAL, 1/4" STUD	1	1	1	1		1													
34	120-120	FLAT METAL, NO. 10 IRRIDITE	2	2	2	2	2	2	1	2	3	3	3								
36	120-137	SPLIT LOCK, 5/8" IRRIDITE	1	1	1	1	1	1	1	1	1	1	1								
43	120-113	SPLIT LOCK, 1/4"	1	1	1	1	1	1													
44	115-4	WASHER, INSULATOR	2	2	2	2	2	2	2	2	2	2	2					-		=	
		MISC.																+		1	-
38	115-62	INSULATOR, RED																			
39	115-79	INSULATOR, BOOT																			
42	120-68	CAP, STUD																			
45	120-345	PULLEY, SPACER											-								_
46	107-21	FAN, BAFFLE																			
47	116-86	TERMINAL, MALE																			
28	120-351	STUD, GROUND																			ĺ

Important: The information contained in this bulletin is intended for use by trained, professional technicians who have the proper tools, equipment, and training to perform the required maintenance described above. This information is NOT intended for 'do-it-yourselfers', and you should not assume that this information applies to your equipment. If you have any questions regarding this information please visit our website at www.prestolite.com, or contact our technical service department at: