

Group:	BLD	Notes:
Form:	SP1006-BLD	Refer to SP1006 -DWG for major component drawing.
Date:	March 5, 2013	Refer to TSB-3003 for hardware kit breakdown.
File:	Alternator Parts List Section	

Component View	Front Housing	Rotor	Coil Assembly	Rear Housing	Stator	Regulator
						
Model	1	2	3	4	5	6
BLD2130GH	A014102328S	A020103414S	A018102307S	A011105913S	A022102423S	8RG2135AS
BLD2192-001	A014102758S	A020103245S	A018102307S	A011105914S	A022102321S	A038102788S
BLD2193-001	A014102758S	A020103245S	A018102307S	A011105914S	A022102423S	A038102788S
BLD2301	A014102328S	A020103245S	A018102307S	A011105913S	A022102423S	8RG2138S
BLD2301GH	A014102328S	A020103414S	A018102307S	A011105913S	A022102423S	8RG2138S
BLD2301H	A014102328S	A020103414S	A018102307S	A011105913S	A022102423S	8RG2138S
BLD2305	A014102328S	A020103245S	A018102307S	A011105913S	A022102423S	8RG2120S
BLD2305GH	A014102328S	A020103414S	A018102307S	A011105913S	A022102423S	8RG2120S
BLD2305H	A014102328S	A020103414S	A018102307S	A011105913S	A022102423S	8RG2120S
BLD2305RM	A014102328S	A020103245S	A018102307S	A011105913S	A022102423S	8RG2120S
BLD2307	A014102328S	A020103245S	A018102307S	A011105913S	A022102423S	8RG2138S
BLD2307GH	A014102328S	A020103414S	A018102307S	A011105913S	A022102423S	8RG2138S
BLD2307H	A014102328S	A020103414S	A018102307S	A011105913S	A022102423S	8RG2138S
BLD2308	A014102328S	A020103245S	A018102307S	A011105913S	A022102423S	8RG2120S
BLD2308GH	A014102328S	A020103414S	A018102307S	A011105913S	A022102423S	8RG2120S
BLD2308H	A014102328S	A020103414S	A018102307S	A011105913S	A022102423S	8RG2120S
BLD2329	A014102328S	A020103245S	A018102307S	A011105913S	A022102321S	8RG2124S
BLD2330	A014102328S	A020103245S	A018102307S	A011105913S	A022102423S	8RG2124S
BLD2367MP	A014106130S	A020103414S	A018106097S	A011106095S	A022102777S	8RG2142MPS
BLD2331GH	A014102328S	A020103414S	A018102307S	A011105578S	A022104186S	8RG2129S
BLD2333GH	A014102328S	A020103414S	A018102307S	A011105578S	A022104186S	8RG2135AS
BLD3194-001	A014102758S	A020103245S	A018102782S	A011105917S	A022102777S	A038102788S
BLD3314	A014102328S	A020103245S	A018102782S	A011105915S	A022102777S	8RG3078S
BLD3314C	A014102328S	A020103245S	A018102782S	A011105915S	A022102777S	8RG3078S
BLD3314GH	A014102328S	A020103414S	A018102782S	A011105915S	A022102777S	8RG3078S
BLD3314HC	A014102328S	A020103414S	A018102782S	A011105915S	A022102777S	8RG3078S
BLD3315	A014103285S	A020103245S	A018102782S	A011105916S	A022102777S	8RG3094S
BLD3315GH	A014103285S	A020103414S	A018102782S	A011105916S	A022102777S	8RG3094S
BLD3320	A014103285S	A020103245S	A018102782S	A011105916S	A022102777S	8RG3094S
BLD3338GH	A014103285S	A020103245S	A018102782S	A011105916S	A022102777S	8RG3088S
BLD3365GH	A014103285S	A020103414S	A018102782S	A011105916S	A022102777S	8RG3094S
BLD3368HC	A014102328S	A020103414S	A018102782S	A011105915S	A022102777S	8RG3096S
BLD3368GH	A014102328S	A020103414S	A018102782S	A011105915S	A022102777S	8RG3096S

To convert alternators to use a remote regulator replace existing regulator with A038102788S cover (See TSB-1112 for detailed procedure).

Important: The information contained in this bulletin is intended for use by trained, professional technicians who have the proper tools, equipment, and training to perform the required maintenance described above. This information is NOT intended for 'do-it-yourselfers', and you should not assume that this information applies to your equipment. If you have any questions regarding this information please visit our website at www.prestolite.com, or contact our technical service department at:

Group:	BLD	Notes: Refer to SP1006 -DWG for major component drawing. Refer to TSB-3003 for hardware kit breakdown.
Form:	SP1006-BLD	
Date:	March 5, 2013	
File:	Alternator Parts List Section	

Component View	Fan	Hardware kit	Overhaul kit	Capacitor	Pulley	Sense Lead Assy
						
Model	7	8	9	10	11	12
BLD2130GH	A041102916S	K212104266S	K183104259S	N/A	K176059473S	A049104702S
BLD2192-001	A041102191S	K212104266S	K183104259S	N/A	K176059473S	
BLD2193-001	A041102191S	K212104266S	K183104259S	N/A	K176059473S	
BLD2301	A041102916S	K212104266S	K183104259S	N/A		
BLD2301GH	A041102916S	K212104266S	K183104259S	N/A		
BLD2301H	A041102916S	K212104266S	K183104259S	N/A		
BLD2305	A041102916S	K212104266S	K183104259S	N/A		
BLD2305GH	A041102916S	K212104266S	K183104259S	N/A		
BLD2305H	A041102916S	K212104266S	K183104259S	N/A		
BLD2305RM	A041102916S	K212104266S	K183104259S	N/A		
BLD2307	A041102916S	K212104266S	K183104259S	N/A		
BLD2307GH	A041102916S	K212104266S	K183104259S	N/A		
BLD2307H	A041102916S	K212104266S	K183104259S	N/A		
BLD2308	A041102916S	K212104266S	K183104259S	N/A		
BLD2308GH	A041102916S	K212104266S	K183104259S	N/A		
BLD2308H	A041102916S	K212104266S	K183104259S	N/A		
BLD2329	A041102916S	K212104266S	K183104259S	N/A		
BLD2330	A041102916S	K212104266S	K183104259S	N/A		
BLD2367MP	A041103292S	K212104260S	K183104259S	N/A		
BLD2331GH	A041102916S	K212104266S	K183104259S	N/A		
BLD2333GH	A041102916S	K212104266S	K183104259S	N/A		A049104702S
BLD3194-001	A041102191S	K212104266S	K183104259S	N/A	K176059473S	
BLD3314	A041102191S	K212104266S	K183104259S	N/A		
BLD3314C	N/A	K212104266S	K183104259S	N/A		
BLD3314GH	A041102916S	K212104266S	K183104259S	N/A		
BLD3314HC	A041103292S	K212104266S	K183104259S	N/A		
BLD3315	A041103292S	K212104266S	K183104259S	N/A		
BLD3315GH	A041103292S	K212104266S	K183104259S	N/A		
BLD3320	4943189T90S	K212104266S	K183104259S	N/A		
BLD3338GH	A041103292S	K212104266S	K183104259S	N/A		
BLD3365GH	A041103292S	K212104266S	K183104259S	N/A		
BLD3368HC	A041102916S	K212104266S	K183104259S	N/A		
BLD3368GH	A041102916S	K212104266S	K183104259S	N/A		

* The external capacitor used on these models has been relocated inside the voltage regulator.
To service this capacitor, a voltage regulator must be purchased.

Important: The information contained in this bulletin is intended for use by trained, professional technicians who have the proper tools, equipment, and training to perform the required maintenance described above. This information is NOT intended for 'do-it-yourselfers', and you should not assume that this information applies to your equipment. If you have any questions regarding this information please visit our website at www.prestolite.com, or contact our technical service department at: